

USER MANUAL



FCC ID: 2AOZM-POWERHBQPRO-1

32441 POLKA TRULY WIRELESS EARBUDS

Package includes:

TWS earbuds x2

Charging case x1

User manual x1

Micro USB charging cable x1

About Earbuds:



1. Function Key
2. Ear silicone cap
3. Ear noise reduction
4. Mic and indicator light
5. Earbud charging input



Power ON/OFF: Press and hold function key ① (left or right earbud) for 3-5 seconds

Play/Pause: Press function key ① (left or right earbud) one time

Answer/Hang up: Press function key ① (left or right earbud) one time

Move to previous: Press function key ① (left earbud) 2 times

Move to next music: Press function key ① (right earbud) 2 times

Volume up: Press function key ① (left earbud) 3 times to increase volume

Volume down: Press function key ① (right earbud) 3 times to reduce volume

Charging the case:

1. Insert the charging cable into the Micro USB input port & the LED indicator will flash red.
2. After charging is completed, the LED indicator will turn red without flashing.

Charging the earbuds

1. Put the earbuds on the charging case and the LED indicator will flash red when it is charging.
2. After charging is complete, the LED indicator will turn blue without flashing.

Bluetooth pairing (first time pairing):

1. Power on Bluetooth earbuds.
2. Bluetooth earbuds will automatically enter pairing mode (flashing blue light).
3. Search for "32441" on pairing device (refer to the user manual of device).
4. Enter password/pin is "0000" if prompted.
5. The pairing process will finish automatically.

General Note

- Make sure the device is charged fully before using for the first time. Please use the included micro USB Cable for charging.
- In order to maintain the power of battery, charge and discharge the device every 3 months, even if you do not use it.

Specification:

Item No.: 32441

Charging case

Capacity (Charging case): 300mAh / 3.7V (1.48Wh)

Input: 5V / 300mA

Charging time: 1 hour

Earbuds

Capacity (Earbuds): 50mAh / 3.7V (0.185Wh)

Input: 5V / 50mA

Charging time: 30min

Play time: 5 hours

Wireless range: 30 feet

After fully charged, the case can charge the earbuds 3 times.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warning: Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C)

